Maestro Pro
Location of Data Plate



The left and right masks are shown partially open in the picture at right. The masks are opened by pulling on the mask from the side of the unit. To fully open the mask to expose the entire data plate leave at least 6” between the unit and the side wall.